

Samsung Devices Supported for TrustCall Service 30 Day Trial

- **Samsung Galaxy S6 edge+**
SM-G928F, SM-G928G, SM-G928K, SM-G928S, SM-G928A, SM-G928P, SM-G928T, SM-G928V, SM-G928W8, SM-G9287, SM-G928I
- **Samsung Galaxy S6**
SM-G920F, SM-G9200, SM-G920K, SM-G920L, SM-G920S, SM-G920A, SM-G920P, SM-G920T, SM-G920V, SM-G920R4, SM-G920W8, SM-G920I
- **Samsung Galaxy S6 edge**
SM-G925F, SM-G9250, SM-G925K, SM-G925L, SM-G925S, SM-G925A, SM-G925P, SM-G925T, SM-G925V, SM-G925W8, SM-G925I
- **Samsung Galaxy S6 Active**
SM-G890A
- **Samsung Galaxy S5**
SM-G900F, SM-G900FD, SM-G900FQ, SM-G900FZ, SM-G900H, SM-G900A, SM-G900M, SM-G900P, SM-G900T, SM-G900V, SM-G900R4, SM-G900W8, SM-G900K, SM-G900L, SM-G900S, SM-G9006, SM-G9009, SM-G900I, SM-G9008, SM-G9009, SM-G900R6, SM-G900D, SCL-23, SC-04F, SM-G901F (Galaxy S5 plus)
- **Samsung Galaxy S5 Mini**
SM-G800H, SM-G800HQ, SM-G800R4, SM-G800F
- **Samsung Galaxy S5 Sport**
SM-G860P
- **Samsung Galaxy S5 Active**
SM-G870A, SM-G870F, SM-G870W, SM-G870D
- **Samsung Galaxy S4 and S4 Active**
GT-i9500, SHV-E300K/L/S, GT-i9502, GT-i9505, SGH-I337, SGH-M919, SCH-I545, SPHL720, SCH-R970, GT-I9515, GT-i9508, SCH-I959, SGH-N045, GT-I9295, SGH-I537 (Galaxy S4 Active)
Note: Samsung Galaxy S4 devices require Android 5.0 (Lollipop) firmware.
- **Samsung Galaxy S4 Zoom**
SM-C101 (3G), SM-C105 (LTE)
- **Samsung Galaxy S3**
GT-i9300, GT-9305, GT-i9308, SCH-i939, SGH-N035, SHV-E210K/L/S, SHW-M440S
- **Samsung Galaxy Note 4**
SM-N910C, SM-N910H, SM-N910K, SM-N910L, SM-N910S (Note 4) SM-N916K, SM-N916L, SM-N916S (Note 4S-LTE), SM-N910F, SM-N9100, SM-N910A, SM-N910T, SM-N910V, SM-N910P, SM-N910R4, SM-N910W, SM-N9106, SM-N9108, SM-N9109
- **Samsung Galaxy Note Edge**
SM-N9150, SM-N915F, SM-N915G, SM-N915A, SM-N915P, SM-N915V, SM-N915T, SM-N915D, SM-N915K, SM-N915S
- **Samsung Galaxy Note 3**

- SM-N9005, SM-N9006, SM-N900A, SM-N900T, SM-N900V, SM-N900P, SM-N900R4, SM-N900W, SM-N9002, SM-N9006, SM-N9008, SM-N9009, SM-N900K, SM-N900L, SM-N900S
- **Samsung Galaxy Note 3 lite/neo**
SM-N750, SM-N750S, SCH-J003, SGH-N098, SM-N7507, SM-N7500Q, SM-N750K, SM-N750L, SM-N750S
 - **Samsung Galaxy Note II**
GT-N7100, GT-N7105, GT-N7102, GT-N7108, SCH-N719, SCH-i605, SCH-R950, SGH-i317, SGH-T889, SPH-L900, SGH-N025, SHV-E250K, SHV-E250L, SHV-E250S
 - **Samsung Galaxy E5 and E7**
SM-E500F, SM-E500H, SM-E500M, SM-E700F, SM-E700H, SM-E700M
 - **Samsung Galaxy Alpha**
SM-G850F, SM-G850Y, SM-G850W, SM-G850K, SM-G850L, SM-G850S
 - **Samsung Galaxy J**
SGH-N075, SC-02F, SGH-N075T
 - **Samsung Galaxy K Zoom**
SM-C115
 - **Samsung Galaxy Light / Avant**
Galaxy Light SGH-T399, Galaxy Avant SM-G386T
 - **Samsung Galaxy Tab A**
Tab A 8.0: SM-T350 (WiFi), SM-T355 (LTE), Tab A 8.0 with Pen: SM-P350 (WiFi), SM-P355 (LTE), Tab A 9.7: SM-T550 (WiFi), SM-T555 (LTE), Tab A 9.7 with Pen: SM-P550 (WiFi), SM-P555 (LTE)
 - **Samsung Galaxy Tab S (8.4, 10.5)**
Tab S 8.4: SM-T700, SM-T705, Tab S 8.4: SM-T707A, SM-T707V, Tab S 8.4: SM-T707D, SC-03G, Tab S 10.5: SM-T800, SM-T805, Tab S 10.5: SM-T807A, SM-T807P, SM-T807T, SM-T807V, Tab S 10.5: SM-T805S, SM-T805K, SM-T805L
 - **Samsung Galaxy TabPRO (8.4, 10.1)**
TabPRO 8.4: SM-T320, TabPRO 8.4: SM-T325, TabPRO 10.1: SM-T520, TabPRO 10.1: SM-T525
 - **Samsung Galaxy TabPRO 12.2**
SM-T900, SM-T905
 - **Samsung Galaxy Tab 4 7.0 LTE**
SM-T235 Samsung, SM-T237P
 - **Samsung Galaxy Tab 4 (8.0, 10.1)**
Tab 4 8.0: SM-T330, SM-T331, SM-T335, Tab 4 8.0: SM-T337A, SM-T337T, SM-T337V, Tab 4 10.1: SM-T530, SM-T531, SM-T535, Tab 4 10.1: SM-T537A, SM-T537V, SM-T537R4
 - **Samsung Galaxy Tab 3 8.0**
SM-T310, SM-T311, SM-T315
 - **Samsung Galaxy Note 8.0**
GT-N5100, GT-N5110, GT-N5120
 - **Samsung Galaxy Note 10.1 (2012)**
GT-N8000, GT-N8005, GT-N8010, GT-N8020, SHV-E230S
 - **Samsung Galaxy Note 10.1 (2014 Edition)**
SM-P600, SM-P601, SM-P605, SM-P607



- **Samsung Galaxy NotePRO 12.2**
SM-P900, SM-P901, SM-P902, SM-P905, SM-P907